## NFO

## **Crimping pliers for uninsulated terminals**

Important when crimping uninsulated terminals and butt space connectors: Uninsulated crimping terminals are pressed together by means of so-called piercing compression. The crimp sleeve is compressed in the middle. The pressing thorn should be set to the separating seam of the sleeve.

